

JAMIE YOUNG Cº

ASSEMBLY INSTRUCTIONS

ITEM:9ORBITALTLCR & 9HARLEQUTLCR

Important Safety Instructions:

- This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature.
- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- This fixture has been rated for up to one (1) **100-watt maximum TYPE A standard incandescent light bulb** (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- This lamp is meant for indoor use.
- **Save these instructions.**

WARNING:

- **To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.**
- **Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.**
- **Keep flammable materials away from lit bulb.**

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts Included:

- (1) Finial (A)
- (2) Shade (B)
- (3) Harp with Harp Caps (C)
- (4) Socket (D)
- (5) Saddle (E)
- (6) Lamp Base (F)

To Assemble:

1. Insert the Harp (C) into the Saddle (E) and lower the Harp Caps until they cover the two-pronged Saddle (E).
2. Unscrew the Finial (A) from the Harp Top (C). Place the Shade (B) over the assembled Harp (C), making sure the Harp Top (C) extends through the hole at the top of the Shade.
3. Attach the Finial (A) onto the Harp Top (C) and tighten to secure the Shade (B).
4. Insert one (1) **100-watt maximum TYPE A standard incandescent light bulb** (not included) into the Socket (D). **DO NOT EXCEED THE SPECIFIED WATTAGE.**
5. Plug fixture into the proper electrical outlet and test fixture.
6. Assembly is complete.

Care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish

