

Hex Light Adjustment. To adjust how much bulb is exposed, raise or lower the Hex “shade” by loosening the strain relief as shown below. Once the desired exposure is achieved, gently tighten the strain relief to hold the shade.

