

# INSTALLATION GUIDE FOR PCMON1616C and PCMON1616MBK

## SAFETY INFORMATION

Released Date: 2023-10-25

Please read and understand this entire manual before attempting to assemble, install or operate the product.


### WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.

### CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.

### TOOLS REQUIRED




Ratings	120Vac, 60Hz	
	Model No.	Wattage
	PCMON1616C	26W
	PCMON1616MBK	26W

## CARE AND MAINTENANCE

- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.


If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at [www.quoizel.com](http://www.quoizel.com).

## PACKAGE CONTENTS



**A** Fixture Body  
x 1

## MOUNTING HARDWARE



**AA** Crossbar  
x 1



**BB** Mounting Screw  
x 2




**CC** Wire Connector  
x 3



**DD** Outlet Box Screw  
x 2



**EE** Wall Anchor  
x 2




**FF** Screw  
x 2

**INSTALLATION**

1

Install Crossbar




Outlet Box

1/4" Hole

2

Wiring



White wire from supply

White wire from fixture

Black (or red) wire from supply

Black wire from fixture


Ground wire from supply

Ground wire from fixture

Green ground screw

3

Install Fixture Body



**Your installation is now complete! Restore electricity and save this sheet for future reference.**