


ASSEMBLY INSTRUCTIONS

AFS-001



1. Carefully remove all parts from the box and remove any plastic coverings from the lamp components.

(2) Screw the Assembly(2) onto the Lamp Body(1).

(3) Put the Harp(3) onto the Saddle of Assembly(2).

(4) Place the Shade(4) onto the Harp(3), then screw it with the Finial(5) tightly.

(5) Screw the Bulb(6) into the Socket.

Note: Bulb not included. Surya recommends using an LED bulb.

CAUTION: TO REDUCE RISK OF FIRE,
USE **MAX 100-WATT TYPE A**
LAMP OR USE MAXIMUM 13-WATT
SELF-BALLASTED LAMP OR LAMP ADAPTER,
120V 60Hz AC ONLY MADE IN CHINA **E533168**

ATTENTION: AFIN DE RÉDUIRE LE RISQUE D'INCENDIE,
UTILISER UNE **MAX** AMPOULE TYPE A DE 100
WATTS OU UTILISER UNE **MAXIMUM 13 WATTS**
AUTOBALLASTÉE LAMPE OU LAMPE ADAPTATEUR,
120V 60Hz C.A. SEULEMENT FABRIQUÉ EN CHINE **E533168**

CAUTION: IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

NOTE : The drawing of the lamp
body is for reference only.

Made in China

Dear Customer,

Thank you for purchasing this quality lamp. It has been manufactured to meet the highest quality standards. Please carefully read the following precautions before use:

- When unpacking and assembling, avoid pulling on the wire too forcefully to prevent disconnection.
- Use only the bulb and wattage specified in these instructions or as indicated on the label attached to the socket.
- Do not replace the bulb while the lamp is plugged into an electrical outlet.
- Avoid using the lamp outdoors, near water, or other liquids.
- Unplug the lamp from the outlet before cleaning or removing any parts.
- Use a soft cloth for cleaning. Avoid using chemicals or abrasive cleaners.
- Remove the cellophane cover from the shade before using the lamp.
- During shipment, the socket cover may have become loose. Before inserting the bulb, ensure the socket cover is securely in place.