



**T-20  
TORX**

If you have a problem, question, or request, call  
your local dealer, or Steelcase Line 1 at  
**888.STEELCASE** (888.783.3522)  
for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico,  
and the U.S. Virgin Islands, call: 1.616.247.2500)

Or visit our website: [www.steelcase.com](http://www.steelcase.com)

© 2013 Steelcase Inc.  
Grand Rapids, MI 49501  
U.S.A.

Printed in U.S.A.

1. Use Torx T-20 driver to remove arm cap screw.
2. Push nose of arm cap away from top of arm to un-snap it from arm cap hooks.
3. Reverse procedure to install replacement arm cap.

