VISUAL COMFORT & CO.

STUDIO COLLECTION

NIDO FLOOR LAMP

KT1381MBK1

General Product Information:

STANDARD INSTALLATION	INDOOR USE	POLARIZED PLUG
DIMMER COMPATIBLE	DRY LOCATION	CLEAN WITH SOFT DRY CLOTH ONLY - NO HARSH CHEMICALS!
WARNING — RISK OF ELEKTRICAL SHOCK	ETL LISTED Intertek	

CAUTION—RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.

SAVE THESE INSTRUCTIONS!

DANGER! SHOCK HAZARD DANGER!

Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.

LAMP SHADE

FINIAL

LAMP

SCREWS

SOCKET

SPANNER WRENCH

STEMS

PLUG

BASE

INSTRUCTIONS

1. Carefully unbox and examine all the items included in the packaging of the lamp.
2. Screw the stems into the base of the lamp.
3. Attach the portion of the lamp that holds the lamp socket to the stems and use the provided spanner wrench, hex nut and washers to secure it in place.
4. Affix the top cover to the socket assembly with the screws provided.
5. Screw the lamp into the socket (see label for Max wattage information).
6. Assemble the lamp shades together with washers, nut and finial.
7. Place the shades on the fixture and use the screws to secure the shade assembly to the socket assembly.
8. Remove the protective cover from the plug portion of the power cord and plug it in into a functioning electrical outlet.
9. Use the switch to turn the lamp on and off to test that it functions properly.