VISUAL COMFORT & CO.

STUDIO COLLECTION

BALLEROY CHANDELIER







FIXTURE PARTS

- A. Junction box
- B. Wires and Wire nuts
- C. Mounting plate
- D. Mounting screws
- E. Canopy
- F. Half Ball
- G. Top Stem
- H. Collar nut
- I. Fixture
- J. Fixture arms
- K. Shade
- L. Bulb (Not Included)

INSTRUCTIONS

I. Preparing the Fixture

- 1. Determine the desired height of the fixture and use the appropriate number of stems (5 included) to assemble the fixture to preference.
- 2. Feed the fixture and ground wires through the stems being used.
- 3. Attach the collar nut, canopy and half ball to the top stem.
- 4. Screw all the stems together, then screw the stem assembly on to the top of the fixture
- 5. Install the mounting plate to the junction box.
- 6. Screw the half ball to the top stem., then slide the half ball assembly onto the mounting plate.

II. Wiring the Fixture

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
- 2. In connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
- 3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) fixture wire (black or round and smooth, depending on the fixture) and hot power line wire from the junction box (hot to hot)
 - b) fixture wire (white or square and rigid, depending on the fixture) and neutral power line wire from the junction box (neutral to neutral)
- 4. Carefully tuck all wires into the junction box.

III. Installing the Fixture

- 1. Install the canopy to the junction box and secure it with the collar nut.
- 2. Insert lightbulbs into the sockets, referring to the label on the socket for Max Wattage information.
- 3. Adjust the shades as needed to face up or down.