3

2 Back out (do not remove) the set screw on the conical

connector with the provided Allen wrench.

3 Pull the coaxial cable out.

1.0

## Mezz Pendant 700FJMEZ Ð VISUAL COMFORT & CO. MODERN COLLECTION **GENERAL PRODUCT INFORMATION:** Intertek This product is ETL listed and suitable only for indoor dry locations and approved for use at any height above the finished floor. **Adjust The Fixture Height 1**A 1C ALLEN WRENCH SET SCREW 5 4 Cut the coaxial cable to the desired length. 5 Gently twist the end of the coaxial cable between thumb **1** Back out (do not remove) the set screw on tip of the and forefinger. connector with the provided Allen wrench. 1D 1B SURFACE ALLEN WRENCH PLATE 6 SET SCREW -

•

6 Tap the conical connector on a hard surface with the set screw facing down, so the plate inside drops into place.



7 Feed and push the coaxial cable into the conical connector. The coaxial cable will come to a stop point after being inserted 3/4" into the conical connector.

1



## Assemble the Fixture



## SAVE THESE INSTRUCTIONS!



7400 Linder Ave, Skokie, IL 160077 800.969.3347

## www.visualcomfort.com

©2023 Visual Comfort & Co.. All rights reserved. The Visual Comfort & Co. logo is a registered trademark of Visual Comfort & Co. Visual Comfort & Co. reserves the right to change specifications for product improvements without notification