

# MONETA BATTERY POWERED LAMP

SLTB27127x

## General Product Information



## Safety Information

**SAVE THESE INSTRUCTIONS!**

### CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

**USE MINIMUM 90°C SUPPLY CONDUCTORS.**



**Turn off electrical current at the source before working with any lighting fixture or portable lamp.**

**Install and use this product in adherence with local electrical codes and regulations.**



## INSTRUCTIONS

1. Carefully remove the fixture from the packaging and plug-in with supplied USB cord/plug. Ensure that the product is fully charged before initial use and turn the fixture on.
2. Pay attention to the indicator light, located next to the USB-C port:
  - a. Solid Red: The fixture needs to be charged.
  - b. Green Flashing: The fixture is currently charging.
  - c. Solid Green: The fixture is fully charged.

**Note: It will take approximately 6 hours to fully charge the fixture.**

3. Use the touch-sensitive switch to change the brightness setting.

**CAUTION: Ensure that the silicone USB cover/plug is re-installed after charging to keep dust/moisture out of USB plug area.**