


# ARN1006

## ASSEMBLY & INSTALLATION GUIDE



**INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.**

**ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.**

1. Attached base loader (J) and base (H) to pole (G), letting bottom threaded rod of (G) pass through the center hole of (H) & (J). Slide the washer (K) and screw the nut (L) onto the threaded rod and tighten with T-wrench (N) provided.
2. Pull the wire from the cord exit hole until tight.
3. Remove backing sheet from felt paper (M), and affix the felt paper to the underneath of the lamp base.
4. Insert light bulb (not included) into the socket.
5. Remove protective plastic (O) from electrical plug (P).
6. Plug lamp into wall outlet.
7. ADJUSTMENT INSTRUCTION
  1. Loosen adjustment keys (B), (D) and (F).
  2. Adjust lamp by pulling or pushing lamp pole (E) up or down to desired height and/or swing lamp shade (A) and lamp pole (C) to desired position.
  3. Tighten the adjustment keys (B), (D) and (F).