

ARN3006

ASSEMBLY & INSTALLATION GUIDE

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Insert light bulb (not included) into the lamp holder.
2. Plug lamp into wall outlet.
3. ADJUSTMENT INSTRUCTION
 1. Loosen adjustment keys (A) , (C) and (E).
 2. Adjust lamp by pulling or pushing lamp pole (D) up or down to desired height and/or swing lamp shade (F) and lamp pole (B) to desired position.
 3. Tighten the adjustment keys (A), (C) and (E).

