

Austin Adjustable Floor Lamp Item # S 1350

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Carefully remove all parts from the carton.
- 2. Join pole (C), lamp base (D) and base weight (E) together by aligning the holes and insert bolts (F) to the holes and tighten with Allen wrench (H).
- 3. Pull the wire tight from the cord exit hole.
- Remove the backing sheet of felt paper (G), affix the felt paper to the underneath base weight (E).
- 5. Remove plastic cover (J) from electrical plug (I).
- 6. Plug lamp into wall outlet
- 7. Please touch the switch on the floor by foot to turn on or off the lamp.

Adjustment Instructions:

- 1. Loosen the collar (B).
- 2. Adjust the lamp height by pulling or pushing upper pole (A) up or down to desired height.
- 3. Tighten the collar (B).

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.



