## **ASSEMBLY INSTRUCTIONS**



## Daniela Table Lamp

Item # RL14040

## NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

- 1. Loosen knobs (D) on harp (B).
- 2. Remove Harp (B) from plastic bag and slide into top of harp holder (A)..
- 3. Adjust Harp (B) up or down to get desired height.
- 4. The socket can not show under the shade (E) after the harp is adjusted correctly.
- 5. Put shade (E) (not included) onto the top of harp (B).
- 6. Carefully tighten knobs (D) on harp (B).
- 7. Plug into proper electrical

**Care Instructions:** Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

## RALPH LAUREN