


P-2959 BF USA 493029592

Metallic arch light with adjustable arm. Methacrylate shade.  
Cord dimmer.




WE RECOMMEND TO READ THE INSTRUCTIONS ENTIRELY BEFORE STARTING YOUR INSTALLATION.  
PLEASE SAVE THESE INSTRUCTIONS SO THAT YOU CAN REFER TO THEM A LATER TIME.

- \* Make sure the power has been disconnected before installing the fixture.
- \* Lighting fixtures should be installed only by qualified personnel.
- \* Make sure the bulb never exceeds the maximum wattage specified on the fixture label.
- \* For indoor use only.
- \* Do not use alcohol or disolvents to clean the lamp
- \* For your convenience assembly by two people ist recommended..

### Assembly instructions


1- Take the base out of the package as shown in the annex attached. Loosen the allen screw (A) and remove the disposable piece (J). Figure 1. Figure 1.

1




2- Insert the arm (B) into the arm (C) and fix them using the two screws (D) with the allen wrench provided. Figure 2..

2




3- Insert the arm into the base and fix it using the lateral screw with the allen wrench provided. Figure 3.

3




## Assembly instructions


4- Insert the arm (B) into the shade (E) as shown in figure 4. Place the socket stick (F) into the shade's joint (G) making sure it seats properly. Figure 4.1 and 4.2.



5- Lift the silicone cylinder (H). Fix the shade using the allen screw located on one side of the joint (G) with the allen wrench provided. Figure 5.



6- To adjust the length of the pendant, move the arm (J) back and forth pushing it slightly upwards. Figure 6.



7- Level out the shade moving it slightly until it is completely straight. Figure 7.

