


Radiant

13574 rG

Low Voltage
Input

Note: External power supply may be required.



CAUTION:

Before starting, turn off power
at main circuit panel.

ADVERTENCIA:



Antes de comenzar la instalación,
apague la corriente en el tablero
principal.

ATTENTION:


Coupez l'alimentation avant de
procéder à l'installation.




Calling for backup? Scan above
to contact our team.



www.RBW.com
+1 212 388 0399
support@RBW.com
© 2023, RBW Studio LLC




Wood Disc Configurations		
Finish	Part Number	Description
White Oak	13138	Radiant Wood Disc, White Oak 12 in
Painted White	13139	Radiant Wood Disc, Painted White 12 in
Tzalam	13279	Radiant Wood Disc, Tzalam 12 in
Ebonized Oak	13280	Radiant Wood Disc, Ebonized Oak 12 in
White Oak	13281	Radiant Wood Disc, White Oak 10 in
Painted White	13282	Radiant Wood Disc, Painted White 10 in
Tzalam	13283	Radiant Wood Disc, Tzalam 10 in
Ebonized Oak	13284	Radiant Wood Disc, Ebonized Oak 10 in
White Oak	14318	Radiant Wood Disc, White Oak 8 in
Painted White	14319	Radiant Wood Disc, Painted White 8 in
Tzalam	14320	Radiant Wood Disc, Tzalam 8 in
Ebonized Oak	14321	Radiant Wood Disc, Ebonized Oak 8 in




Wood Square Configurations		
Finish	Part Number	Description
White Oak	14332	Radiant Wood Square, White Oak 12 in
Painted White	14333	Radiant Wood Square, Painted White 12 in
Tzalam	14334	Radiant Wood Square, Tzalam 12 in
Ebonized Oak	14335	Radiant Wood Square, Ebonized Oak 12 in
White Oak	14323	Radiant Wood Square, White Oak 10 in
Painted White	14324	Radiant Wood Square, Painted White 10 in
Tzalam	14325	Radiant Wood Square, Tzalam 10 in
Ebonized Oak	14326	Radiant Wood Square, Ebonized Oak 10 in
White Oak	14327	Radiant Wood Square, White Oak 8 in
Painted White	14319	Radiant Wood Square, Painted White 8 in
Tzalam	14329	Radiant Wood Square, Tzalam 8 in
Ebonized Oak	14330	Radiant Wood Square, Ebonized Oak 8 in


This product is made from a natural material and may be subject to warping due to environmental conditions. Please allow parts to acclimate to environmental changes for a minimum of three days prior to installing.



Item	Qty	Part number	Description
1	1	13281	Radiant Wood Disc, White Oak 10 in
2	1	14408-27	Radiant Base Plate Sub-Assembly. 2700K
3	1	14016	White Polycarbonate Diffuser
4	2	91771A952	#8-32 x 3/4" Flat Head (100) machine screw 18-8 SS
5	3	92470A242	#10 x 1/2" Philips Rounded Head Sheet Metal Screw 18-8 SS
6	3	94355A190	#8-32 x 1/4" Flat-Tip Set Screw 18-8 SS




⚠ Driver dimensions and location may vary, consult your order confirmation for details.




Installation - Base Plate Sub-Assembly

1. Connect Red (+) and Black (-) leads to low voltage leads from externally located driver.
2. Fasten Base Plate Sub-Assembly to desired mounting surface with 2 #8-32 Flat Head machine screws.




* Wood Square can be installed in 2 orientations shown below.



Installation - Diffuser to Wood Disc

3. Fasten Radiant Diffuser to Wood Disc using 3 #10 x 1/2" Rounded Head Sheet Metal Screws.



Installation - Diffuser to Base Plate

4. Align Radiant Diffuser with tab on Base Plate Assembly and snap in place.
5. Use 3 included #8-32 Set Screws to fasten Radiant Diffuser in place.
6. Congratulations! End of guide.