


SEQUEL[®] STUDIO 6617

MULTIFUNCTION CABINET

USER MANUAL

LET'S GET STARTED.



DESIGN MATTHEW WEATHERLY

BDi

BDIUSA.COM



Congratulations on the purchase of your Sequel Studio cabinet from BDI. Your multifunction cabinet has been designed to provide a lifetime of enjoyment. This manual will provide assembly instructions and other helpful information to ensure you get the most out of your product. Please save it for future reference.

Your Sequel Studio has been engineered for simple assembly. Please follow these directions carefully to prevent any damage.


Should you need further assistance, contact BDI at customerservice@bdiusa.com.

ENJOY!

HARDWARE AND COMPONENTS


Unpack and identify the parts listed below. The assembly workspace should be a non-marring surface, such as carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com. For all other concerns, please contact your BDI retailer.

Do not use power tools for the assembly of this product.



M4 x 35 Screw (H1)

QTY: 6




Leveler Wrench (T1)

QTY: 1



TOOL REQUIRED (NOT INCLUDED)

Phillips Screwdriver



Cabinet (C1)

QTY: 1



Drawer Pull (C2)

QTY: 3




Glass Top (C3)

QTY: 1



Small File Bar (C4)

QTY: 2



Long File Bar (C5)

QTY: 1





File Bar Clip (C6)


QTY: 4

STEP 1. ATTACH DRAWER PULLS

ASSEMBLY

- Open drawers of **Cabinet (C1)** and cut ribbons off.
- Attach **3 Pulls (C2)** with **6 Screws (H1)** using a **Phillips Screwdriver (not included)**.


	SCREW – H1	QTY 6
	NOT INCLUDED Phillips Screwdriver	1



STEP 2. PLACE GLASS TOP

ASSEMBLY


- Carefully place **Glass Top (C3)** in position on rubber bumpers.




ASSEMBLY

STEP 3. ATTACH FILE BARS AND CLIPS


- Your Multifunction Cabinet can accommodate Letter, A4, and Legal file size.
- Please refer to the images and instructions below to place the File Bars in the correct locations.




- For forward facing files, attach **File Bar Clips (C6)** to each end of **Small File Bars (C4)**.
- Place **File Bars** such that the **File Bar Clips** go into the appropriate grooves in the drawer's front and back panels.




- For sideways facing letter files, attach **File Bar Clips (C6)** to each end of **Long File Bar (C5)**.
- Place the **Long File Bar** such that the **File Bar Clips** go into the grooves in the drawer's side panels.
- For side facing legal files, do not use a file bar at all. Simply hang the files on the drawer's front and back rails.



- Using a level (not provided), check that the cabinet is level side to side and front to back.
- If adjustments are needed, use the **Leveler Wrench (T1)** to fine-tune the levelers until the cabinet is properly balanced.
- For carpeted surfaces, recheck front-to-back leveling after loading the cabinet and opening the drawer.
- This ensures the cabinet remains level during use and minimizes risk of tip-over.

	LEVELER WRENCH – T1	1
---	---------------------	---



Your BDI furniture has been constructed with the finest materials, carefully manufactured, and designed to last a lifetime. Regular furniture care will prolong your enjoyment and keep it looking its best. Here are some general tips for taking care of BDI furniture. Your surfaces may vary.

GLASS

Glass surfaces are maintained using household glass cleaner and a paper towel or cloth.

SATIN-ETCHED GLASS

This uniquely smooth-to-the-touch glass surface can be regularly maintained using household glass cleaner and a paper towel or cloth.

A 'Magic Eraser' removes minor scratches or scuffs not eliminated using a paper towel or cloth. 'Magic Eraser' is a melamine foam product available at any grocery store or home improvement center. Dampen the entire glass surface and the Magic Eraser, then rub the whole surface in broad, even strokes using moderate pressure. Clean and dry the surface with a paper towel. Check for results and repeat as necessary. Any scratches or scuffing not eliminated by one of the above methods can often be addressed by 'refreshing' the glass. This process should not be required more than once per 6-12 months. See this brief video for the simple method: www.bdiusa.com/glass

WOOD

Wood surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. Do not use glass cleaner on wood. If moisture remains, dry the surface with another cloth. If needed, a gentle, non-abrasive cleanser may be used, but wipe away all cleaner residue and dry the surface with a cloth.

BDI's wood finishes feature natural hardwood solids and veneers. Wood is a product of nature and—unlike man-made materials that can be manufactured to strict and consistent specifications—has natural imperfections that are part of its appeal and character. Every piece of wood differs from every other, even when coming from the very same tree. As such, grain, texture, and tone variation should be expected from one panel or piece of furniture to the next.

While BDI's stained wood finishes are stable in tone & appearance, all finishes are subject to some degree of discoloration with prolonged exposure to direct sunlight. Please avoid positioning your BDI cabinet in any area with ample direct sunlight. To learn more about the features of natural wood, visit www.bdiusa.com/wood

METAL, PORCELAIN, & PAINTED SURFACES

Surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. If moisture remains, dry the surface with another cloth. If needed, a gentle, non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

WARRANTY

BDI warrants to the original purchaser that for the below-stated warranty term, BDI will replace any product, part, or component covered by this warranty that fails under normal use as a result of a defect in material or workmanship. The decision to replace a complete product versus the part or component in question will be at BDI's sole discretion.

Residential Use: BDI Furnishings carry warranty coverage for three (3) years from the date of product delivery, as shown on your sales receipt/documentation. Select chairs carry coverage for five (5) years from the date of product delivery.


Commercial Use: BDI Furnishings carry warranty coverage for one (1) year from the date of product delivery, as shown on your sales receipt/documentation. Select chairs carry coverage for five (5) years from the date of the product delivery, based on an 8-hour daily use pattern.

BDI reserves the right to refine or update its warranty from time to time. See the complete and latest warranty document at www.bdiusa.com/warranty.

PRODUCT REGISTRATION

Registering your new BDI product allows us to send you important product updates, service information, and helpful hints related to your BDI products.

Register today, and you will be **entered to win free a BINK table** from BDI: www.bdiusa.com/register





WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO HELP PREVENT TIP-OVER:

- Install tip-over restraint.
- Place heaviest items in lower compartments.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

USE OF TIP-OVER RESTRAINT MAY REDUCE—BUT NOT ELIMINATE—THE RISK OF TIP-OVER.



BDIUSA.COM

These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Sequel Studio & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2025, BDI | V.12.18.2025

Made in Vietnam.