


RENGØRINGSSÆT / CLEANING KIT

VP Globe & Panto





RENGØRING

Rengøring og vedligehold af akrylskaller til VP Globe og Panto

Følg denne beskrivelse nøje:

- 1.** Rengør skallerne med den medfølgende klud (1 CLOTH), således overfladen er helt tør og fri for støv.
- 2.** Hæld lidt væske (1 FLUID) på kluden (1 CLOTH). Før kluden på skallen først lodret, derefter vandret - IKKE cirkulære bevægelser!. Kluden må IKKE grides på skallen.
- 3.** Forsæt til skallen er helt klar og ren.

Denne behandling bevirker, at skallen får en antistatisk overflade, således skallen bliver mindre modtagelig for støv.




FJERNELSE AF RIDSER

Pasta til brug for fjernelse af mindre ridser på skallerne til VP Globe og Panto

Følg denne beskrivelse nøje:

- 1.** Påfør en 5 cm lang streng af pastaen (2 PASTA) direkte på den medfølgende klud (2 CLOTH). Denne mængde rækker til et område af ridser på størrelse med en håndflade.
- 2.** Pastaen påføres skallen i cirkulære bevægelser i 3-5 minutter.
- 3.** Polerer dernæst med en klud (100% bomuld) opvredet i varmt vand. Kluden, som anvendes, skal være helt ren!
- 4.** Når den ønskede effekt er opnået, skal der afsluttes med beskrivelsen øverst på denne side (RENGØRING).





CLEANING OF ACRYLIC SHELL

Cleaning instructions:

- 1.** Clean the outer acrylic shells with the cloth included (1 CLOTH), so that the surface is completely dry and free of dust.
- 2.** Pour a little of the liquid (1 FLUID) onto the cloth (1 CLOTH). Move the cloth on the shell first vertical, then horizontal – do NOT move in circular movements!. The cloth should NOT be rubbed on the shell.
- 3.** Proceed until the shell is completely clear and clean.

This treatment causes the shell to get an antistatic surface so the shell becomes less susceptible to dust.



REMOVAL OF SCRATCHES

Paste for the removal of minor scratches on the acrylic shells to VP Globe and Panto

Follow this description in detail:

- 1.** Apply a 5 cm long strand of paste (2 PASTE) directly on the supplied cloth (2 CLOTH). The amount of paste described will cover an area of scratches of approx 5cm²
- 2.** The paste is applied to the shell in circular movements for 3-5 minutes.
- 3.** Polish then with a damped hot cloth (made of 100% cotton). The cloth must be completely clean!
- 4.** Once the desired effect is achieved you must concluded with the cleaning instructions described at the top of this page.



Verner Panton (1926-1998) blev uddannet på Det Kongelige Danske Kunstakademi i København. Han var en inspirerende og farverig person med en speciel følelse af figurer, lys, rum og funktion.

Verner Panton betragtes i dag som en stor inspirator til udviklingen af design i anden halvdel af det 20. århundrede.

Verner Panton (1926-1998) trained at the Royal Danish Academy of Fine Arts in Copenhagen. He was an inspirational and colourful person with a special sense of shapes, light, function and space.

Verner Panton is regarded today as a major contributor to the development of design in the second half of the 20th century.

www.verpan.dk