



## Content



## Drilling template



NB!  
Unless otherwise specified mounting screws are not provided by Frandsen  
If relevant: All drivers must be mechanically fastened.  
If relevant: turn of power before changing lightsource  
If relevant: Loose cords on wall mounted luminaires must be effectively fixed to the wall if exceeding a length of 300mm  
If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

## Mounting instructions for 16 54076 Bracket for multiple lamp mounting

## Mounting

Step 1  
Mount the cable by using one or more mounting screws depending on how many brackets are to be connected

Step 2  
Mount the distance part in the remaining mounting holes

Step 3  
Make sure the distance part is completely horizontal or vertical before mounting the next bracket

Step 4  
Mount the lampbracket onto each wall bracket by using the three M4 screws

