

## ASSEMBLY INSTRUCTIONS

### ITEM DESCRIPTION:

ITEM NO.: DF109	NAME: Istanbul Semi Flush
MATERIAL TYPE: Brass	FINISH: Vintage Brass
SOCKET TYPE: E26	SOCKET QTY: 2
BULB WATTAGE: 40W BULB / 10W SBCFL / 9 W SBLED	
VOLTAGE: 125V	ITEM NET WEIGHT: 16.87 L

### PARTS INCLUDED:

Mounting Plate	Qty 1 Pc
Canopy	Qty 1 Pc
Hanging Pipe	Qty 4 Pcs

### HARDWARE INCLUDED:

Mounting Screws	Qty: 02
Plastic Wire Connector	Qty: 02
Ground wire Screw	Qty: 01

### TOOLS NEEDED (Not Included):

- 1 Screwdriver
- 2- People Recommended

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



### PRE-ASSEMBLY

1. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
3. Included are (1) 3", (1) 6" pipe and (2) 12" pipes. Determine which of these you will need to reach your desired length. At least (1) 3" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the threaded part of the pipes toward the ceiling.
4. Screw each pipe to each other starting with the one closest to the Main Body and moving upwards to the canopy.
5. There is an Allen screw with each pipe and which should be tightened with the help of Allen wrench included with the hardware once pipes are assembled with each other as per desired height.

### TO ASSEMBLE:

1. Gently pull wiring down from ceiling junction box and allow it to hang.
2. Remove the mounting plate from the canopy by loosening the canopy screws with a screwdriver.
3. Determine the Pipe length desired and if necessary, remove extra Pipes from assembly. The electric supply wire that is go through the pipe should be cut off 12 inches longer than the pipe. Cut the braided copper ground wire the same length. Split the supply wire down the center by a length of 3 inches and strip  $\frac{3}{4}$  inch of insulation off the end of each wire. If you look very closely, you will notice that the plastic insulation of one of the two split wires has a rib on the outside edge. This ribbed wire is the "neutral" wire and the other is the "hot" wire; you will need to remember the difference later on when you connect these to the house wires in the electrical outlet box.
4. Insert the two stripped wires and the braided copper ground wire through the nipple assembly, locknut, mounting plate and mounting strip. Using the wire nuts, attach the ribbed wire to the white "neutral" house wire and the un-ribbed wire to the black "hot" house wire. Secure the wire nuts with black electrical tape. Connect the braided copper ground wire to the green ground screw marked "GRD" on the mounting strip. It is imperative that the outlet box in your home be properly grounded.
5. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.** Always make sure that no wire strands are outside of the wire nut connectors.
6. Gently push the wiring back into the outlet box. Screw the nipple assembly, locknut and canopy plate into the mounting strip and turn until the canopy is snug against the ceiling. Do not support the fixture from the electrical cord.
7. Insert (2) TYPE A 40W BULB / 10W SBCFL / 9 W SBLED (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
8. Restore power to junction box and test fixture.

### CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

A R T E R I O R S