

Onda Sconce  
*Assembly Guide*



Thank you for choosing In Common With. Please confirm that you received all of the components pictured in this guide, and reach out to us if anything is missing. It's rare, but it happens. We hope you enjoy your fixture. With proper care, it should last a lifetime.

Have questions? Please contact us at [support@incommonwith.com](mailto:support@incommonwith.com).




**CAUTION!**

Electrical shock risk. Turn off electrical power at the main fuse box or circuit panel before beginning installation, servicing the light, or installing accessories. We recommend working with a qualified electrician familiar with the type of work you'd like done.


**ATTENTION!**

Risque de choc électrique. Coupez l'alimentation électrique au niveau de la boîte à fusibles principale ou du panneau de circuits avant de commencer l'installation, l'entretien de la lumière ou l'installation d'accessoires. Nous vous recommandons de travailler avec un électricien qualifié familier avec le type de travail que vous souhaitez effectuer.

Onda Sconce, Small  
Components




Onda Small Canopy Assembly




Backplate




Embellishments (4)




Canopy Screws (4)



Diffuser (x1)




Onda Small Canopy Glass Shade




Hardware Pack

### Step 1




Before beginning installation, turn off electrical power at the main fuse box or circuit panel.

### Step 2




Mount backplate to the junction box using a phillips head screwdriver to tighten the mounting screws.

### Step 3




Use the wago clips to connect the fixture's wires to the corresponding wires from the junction box in the wall or ceiling. White is neutral; Black is live; Green/Yellow is ground. One ground wire will be attached to the backplate, the other ground wire should come from the junction box. If you are using 0-10V dimming connect the pink and purple wires to the dimming system. If you are using TRIAC or ELV dimming, simply cap the wago on the ends of the purple and pink wire. If needed use a wire stripper to remove 3/8" of the insulation from each wire before inserting them into the corresponding wago clip.

### Step 4




Align the holes of the backplate with the holes of the canopy cover. Secure the canopy cover in place with the canopy screws and screwdriver found in the hardware pack.

### Step 5




Attach the diffuser to the metal hardware by rotating clockwise until fixed in place.

### Step 6




Gently place the Onda glass shade over the canopy assembly and align the four holes. Thread the embellishment screws through the holes on the sides of the glass shade into the corresponding holes in the tabs on the canopy assembly. Tighten in place and adjust the embellishment so that it is in the shape of a diamond.

## Step 7




Turn the power back on at the main fuse box or circuit panel you disabled before installation. Turn on the light :)

Onda Sconce, Medium  
Components




Onda Medium Canopy Assembly




Backplate




Embellishments (4)




Canopy Screws (4)



Diffuser (x2)




Onda Medium Glass Shade



Hardware Pack




### Step 1




Before beginning installation, turn off electrical power at the main fuse box or circuit panel.

### Step 2




Mount the backplate to the junction box using a Phillips head screwdriver to tighten the mounting screws.

### Step 3




Use the wago clips to connect the fixture's wires to the corresponding wires from the junction box in the wall or ceiling. White is neutral; Black is live; Green/Yellow is ground. One ground wire will be attached to the backplate, the other ground wire should come from the junction box. If you are using 0-10V dimming connect the pink and purple wires to the dimming system. If you are using TRIAC or ELV dimming, simply cap the wago on the ends of the purple and pink wire. If needed use a wire stripper to remove 3/8" of the insulation from each wire before inserting them into the corresponding wago clip.

### Step 4




Align the holes of the backplate with the holes of the canopy cover. Secure the canopy cover in place with the canopy screws and screwdriver found in the hardware pack.

### Step 5




Attach the diffusers to the metal hardware by rotating clockwise until fixed in place.

### Step 6




Gently place the Onda glass shade over the canopy assembly and align the four holes. Thread the embellishment screws through the holes on the sides of the glass shade into the corresponding holes in the tabs on the canopy assembly. Tighten in place and adjust the embellishment so that it is in the shape of a diamond.

## Step 7




Turn the power back on at the main fuse box or circuit panel you disabled before installation. Turn on the light :)

Onda Sconce, Small, Plug-in  
Components




Onda Small Plug-in Assembly




Backplate




Embelishments (4)



Canopy Screws (4)



Diffuser (x1)




Onda Small Glass Shade




Screwdriver

### Step 1




Mount the Backplate to the wall using anchors appropriate for your wall material (not provided). Consult a qualified professional if needed.

### Step 2




Align the holes of the backplate with the holes of the canopy cover. Secure the canopy cover in place with the canopy screws and screwdriver found in the hardware pack.

### Step 3




Attach the diffuser to the metal hardware by rotating clockwise until fixed in place.

### Step 4




Gently place the Onda glass shade over the canopy assembly and align the four holes. Thread the embellishment screws through the holes on the sides of the glass shade into the corresponding holes in the tabs on the canopy assembly. Tighten in place and adjust the embellishment so that it is in the shape of a diamond.

*Step 5*



Plug in the cord.


*Step 6*




Turn on and dim the light as desired using the inline dimmer located at the middle of the cord.



Onda Sconce, Medium, Plug-in  
Components




Onda Medium Plug-in Assembly




Backplate




Embellishments (4)



Canopy Screws (4)



Diffuser (x2)




Onda Medium Glass Shade




Screwdriver

### Step 1




Mount the Backplate to the wall using anchors appropriate for your wall material (not provided). Consult a qualified professional if needed.

### Step 2




Align the holes of the backplate with the holes of the canopy cover. Secure the canopy cover in place with the canopy screws and screwdriver found in the hardware pack.

### Step 3




Attach the diffusers to the metal hardware by rotating clockwise until fixed in place.

### Step 4




Gently place the Onda glass shade over the canopy assembly and align the four holes. Thread the embellishment screws through the holes on the sides of the glass shade into the corresponding holes in the tabs on the canopy assembly. Tighten in place and adjust the embellishment so that it is in the shape of a diamond.

### Step 5



Plug in the cord.

### Step 6



Turn on and dim the light as desired using the inline dimmer located at the middle of the cord.

Never use scouring pads or abrasive cleaning solutions. If it comes in a bottle, it is bad for your fixture. Instead, we recommend using soft microfiber cloths, which are gentler on our products and the planet.

For Metal: Wipe with a damp or dry microfiber cloth. Please note that our brass is unlacquered, and will darken naturally over time.

For Glass: Wipe clear or colored glass with a damp microfiber cloth. For sandblasted or etched glass, use a dry microfiber cloth. Removable glass shades can be washed carefully in a sink using warm or hot water.

For Ceramic: Wipe with a damp microfiber cloth. Do not submerge in water.