



Customer Service: (702) 361-4345, (800) 525-2655, [customer.services@kalco.com](mailto:customer.services@kalco.com)

## WARNING:


- 1.If you are unfamiliar with electrical wiring, call a qualified electrician to install this unit. More than one person may be necessary to install fixture, make sure you have enough qualified help.
- 2.Turn off the power to the fixture's circuit at the service panel. Use a voltage detector to verify that the power is off.
- 3.DO NOT install bulb which exceeds the maximum wattge specified on the socket label.
- 4.This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

## FIXTURE ASSEMBLY :

- 1 Use (2) 8-32 Screw to fix the crossbar on the J-box, pre-mount a plastic plug on the wall according to frame hole.
2. Connect the main wire with the power supply circuit. See wire connection diagram.  
And adjust the LED tape to requested temperature.
- 3.Use (2) grub screw to fix the frame on the crossbar, then use self-tapping screw to fix frame top to the wall tightly.
- 4.Use round iron sheet to fix the milky white acrylic A on the frame.
- 5.Use grub screw to fix the milky white acrylic B on the frame.
- 6.Hang marble on the frame.



## Wiring Diagram





ASSEMBLY INSTRUCTIONS


529321

Wall sconce

Customer Service: (702) 361-4345, (800) 525-2655, customer.services@kalco.com

- WARNING:
- 1.If you are unfamiliar with electrical wiring, call a qualified electrician to install this unit. More than one person may be necessary to install fixture, make sure you have enough qualified help.
  - 2.Turn off the power to the fixture's circuit at the service panel. Use a voltage detector to verify that the power is off.
  - 3.DO NOT install bulb which exceeds the maximum wattge specified on the socket label.
  - 4.This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Note: Please adjust lamp color temperature before installing back plate.



SWITCH POSITIONS				
1	2	3	4	5
RP CCT 1	RP CCT 2	RP CCT 3	RP CCT 4	RP CCT 5
4000K	3500K	3000K	2900K	2700K