




462 Leap® Chair Back Cushion Replacement



If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500)


Or visit our website: www.steelcase.com

© 2000 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.


Molded Upholstery

1. Remove two screws beneath pivots.
2. Pulling up on cushion, remove it from back shell.
3. Remove staples from bottom of cushion and remove elastic band from slot.
4. Reverse to assemble.




Pillow Upholstery


1. Pulling up on cushion, remove it from back shell.
2. Remove elastic band from slot.
3. Reverse to assemble.




2.



1.



3.



Vest Upholstery

1. Pulling up on cushion, remove it from back shell.
2. Remove elastic band from slot.
3. Reverse to assemble.

