




464 Leap® WorkLounge Arm Cap Replacement (Customer Service)



If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you. (Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500) Or visit our website: www.steelcase.com

© 2005 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.

Underside of Arm

1. Remove arm cap screws from underside of aluminum armrest structure (1a) and remove both arm caps (1b).

2. Line up new arm caps with mounting holes and reattach arm cap screws.

