

COLFAX MEDIUM & LARGE CHANDELIERS


SLC1014; SLC1005

General Product Information



Intertek

SAVE THESE INSTRUCTIONS!



STANDARD INSTALLATION



INDOOR



NEC COMPLIANT JUNCTION BOX



DAMP LOCATION SAFE



BULB(S) (NOT INCLUDED)



CONVERTS TO LED




ADAPTABLE TO SLOPED CEILINGS




PLEASE SEE [visualcomfort.com](http://visualcomfort.com) FOR PRODUCT SPECS



CLEAN WITH SOFT, DRY CLOTH ONLY. NO HARSH CHEMICALS!



BEST PRACTICE: HANDLE FIXTURE WITH GLOVES



Product Warranty



FCC Statement

Suggested/Required Tools



ELECTRIC DRILL



PHILLIPS-HEAD SCREWDRIVER



WIRE CUTTER



PENCIL/MARKER

Safety Information



CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp.  
Install and use this product in adherence with local electrical codes and regulations.





## FIXTURE PARTS

- A. Junction Box
- B. Wire Nuts
- C. Mounting with Screw Collar
- D. Swivel/Half Ball
- E. Canopy
- F. Collar Nut
- G. Stem Assembly
- H. Fixture Base
- I. Shades
- J. Bulbs (Not Included)
- K. Sockets/Shade Bases

## INSTRUCTIONS

### I. Preparing the Fixture

1. Carefully, unbox and examine all the items included in the packaging of the pendant.
2. Determine the desired height of the fixture and complete the stem assembly by screwing the stems together.
3. Feed the fixture wires through the stem assembly, collar nut, canopy, and half ball.
4. Screw the half ball onto the stem assembly. Then screw the stem assembly on top of the fixture.
5. Secure the mounting plate to the junction box using the mounting screws. Then slide the half ball into the screw collar portion of the mounting plate.

### II. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate or a house wire (green or bare copper wire without insulation).
3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
  - a) Hot fixture wire (black, smooth) and hot power line wire from the junction box (hot to hot)
  - b) Neutral fixture wire (white, rigid) and neutral power line wire from the junction box (neutral to neutral)
4. Carefully tuck all wires into the junction box. Place the canopy onto the mounting plate and secure it in place by screwing the collar nut tightly onto the mounting plate.

### III. Installing the Fixture

1. Screw the bulbs into the sockets. Refer to the label on the socket for max wattage information.
2. Complete the installation by installing the shades onto the bulbs.