





EGMONT TALL SCONCE

DJW1161

General Product Information







ETL LISTED  
Intertek

SAVE THESE INSTRUCTIONS!

STANDARD INSTALLATION

INDOOR






NEC COMPLIANT JUNCTION BOX

DAMP LOCATION SAFE

CONVERTS TO LED



BULB(S) (NOT INCLUDED)



PLEASE SEE [visualcomfort.com](http://visualcomfort.com) FOR PRODUCT SPECS

CLEAN WITH SOFT, DRY CLOTH ONLY. NO HARSH CHEMICALS!

BEST PRACTICE: HANDLE FIXTURE WITH GLOVES



Product Warranty

FCC Statement

Tools Required/Suggested



ELECTRIC DRILL

PHILLIPS-HEAD SCREWDRIVER

WIRE CUTTER


PENCIL/MARKER

Safety Information

**CAUTION-RISK OF FIRE**


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


**USE MINIMUM 90°C SUPPLY CONDUCTORS.**



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.





## FIXTURE PARTS

- A. Bulb (Not Included)
- B. Shade
- C. Socket Assembly
- D. Junction Box
- E. Fixture Wires
- F. Mounting Plate
- G. Mounting Screws
- H. Fixture Base
- I. Fixture Screws

## INSTRUCTIONS

### **I. Preparing the Fixture**

1. Separate the mounting plate from the fixture base.
2. Secure the mounting plate to the junction box.

### **II. Wiring the Fixture**

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate or a house wire (green or bare copper wire without insulation).
3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
  - a) Hot fixture wire (white; smooth) to hot power line wire
  - b) Neutral fixture wire (black; textured/ribbed) to neutral power line wire
4. Carefully tuck all the wires into the junction box.

### **III. Installing the Fixture**

1. Mount the fixture onto the mounting plate and secure it in place by installing the fixture screws.
2. Attach the shade by sliding it over the socket assembly.
3. Screw the bulb into the socket to complete installation. Refer to the socket label for max wattage information.