



KENNEWICK MEDIUM POST LANTERN

DJO1092


General Product Information




Intertek




SAVE THESE INSTRUCTIONS!




STANDARD INSTALLATION




OUTDOOR




WET LOCATION SAFE




NEC COMPLIANT JUNCTION BOX




BULB(S) (NOT INCLUDED)




CONVERTS TO LED




PLEASE SEE visualcomfort.com FOR PRODUCT SPECS




BEST PRACTICE: HANDLE FIXTURE WITH GLOVES



CLEAN WITH SOFT, DRY CLOTH ONLY. NO HARSH CHEMICALS!



Product Warranty



FCC Statement

Suggested/Required Tools




ELECTRIC DRILL



PHILLIPS-HEAD SCREWDRIVER



CAULK GUN



WIRE CUTTER

Safety Information


CAUTION-RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

USE MINIMUM 90°C SUPPLY CONDUCTORS.



Turn off electrical current at the source before working with any lighting fixture or portable lamp. Install and use this product in adherence with local electrical codes and regulations.





FIXTURE PARTS

- A. Fixture Cover
- B. Fixture Frame
- C. Glass Panel
- D. Bulbs (Not Included)
- E. Sockets
- F. Mounting Base
- G. Post Screws
- H. Fixture Wires
- I. Ground Wire
- J. Post

INSTRUCTIONS

I. Preparing the Fixture

1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Slide glass panels onto the fixture frame. Secure them with the tabs on the frame.

II. Wiring the Fixture

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. In a connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
 - a) Hot fixture wire (black or smooth, depending on the fixture) and hot power line wire (hot to hot)
 - b) Neutral fixture wire (white or textured/ribbed, depending on the fixture) and neutral power line wire (neutral to neutral)
4. Carefully tuck all wires into the post.

III. Installing the Fixture

1. Secure the mounting base onto the post with the post screws provided.
2. Install light bulbs into the sockets. Refer to the label on the socket for max wattage information.
3. Install the fixture cover to the fixture frame.