# VISUAL COMFORT & CO.

MODERN COLLECTION

# LAUREL MEDIUM SCONCE

KWWS210







## FIXTURE PARTS

- A. Junction box
- **B.** Power Line Wires
- C. Fixture Wires
- D. Wire Nuts
- E. Mounting Plate
- F. Mounting Screws
- G. Fixture Base
- H. Fixture Screws
- I. Allen Wrench
- J. Fixture Stem
- K. LED Rings
- L. Shade Ring

# INSTRUCTIONS

### I. Preparing the Fixture

- 1. Separate the mounting plate from the fixture body by removing the fixture screws with the provided Allen wrench.
- 2. Secure the mounting plate to the junction box using the mounting screws.

### II. Wiring the Fixture

- 1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
- 2. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate or a house wire (green or bare copper wire without insulation).
- 3. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
  - a) Negative (-) fixture wire to the negative (-) output driver wire (negative to negative)
  - b) Positive (+) fixture wire to the positive (+) output driver wire (positive to positive)
- 4. For 0-10V dimming capabilities, connect the purple and pink wires to a compatible dimmer. Cap off these wires, if not using a dimmer.
- 5. Carefully tuck all the wires and wire-nut connections into the junction box.

### III. Installing the Fixture

- 1. Mount the fixture onto the mounting plate and secure it in place by reinstalling the fixture screws using the Allen wrench.
- 2. Install the LED rings onto the fixture stem and secure them in place using the shade ring.