

# BELLE MEDIUM PENDANT

P1253

## General Product Information



Intertek




STANDARD  
INSTALLATION



INDOOR



DAMP LOCATION  
SAFE



NEC COMPLIANT  
JUNCTION BOX



DIMMER  
COMPATIBLE



CLEAN WITH SOFT,  
DRY CLOTH ONLY -  
NO HARSH CHEMICALS!



SAVE THESE  
INSTRUCTIONS!

## Tools Required



PHILLIPS-HEAD  
SCREWDRIVER



WIRE CUTTER

## Safety Information

### CAUTION-RISK OF FIRE

This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


**USE MINIMUM 90°C SUPPLY CONDUCTORS.**



Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.





## FIXTURE PARTS

- A. Junction Box
- B. Mounting Bracket
- C. Mounting Screws
- D. Canopy
- E. Strain Relief with Set Screws
- F. Fixture Cord
- G. Turned Steel break
- H. Fitter
- I. Coupler
- J. Shade
- K. Lamp

## **INSTRUCTIONS**

### **I. Preparing the Fixture**

1. Install the threaded pipe onto the coupler.
2. Secure the fitter with the turned steel break.
3. Determine the wanted height of the fixture by raising the canopy up to the junction box.
4. Loosen the set screw in the strain relief.
5. Move the cord up or down until desired height is reached.
6. Trim the cord leaving enough to make electrical connections.
7. Secure the cord in place by tightening the set screws in the strain relief.
8. Separate the mounting plate from the canopy by unscrewing the cap nuts.
9. Install the mounting plate to the electrical box and secure it with two mounting plate screws.

### **II. Wiring the Fixture**

1. Safety first! Locate the circuit breaker and switch it off to cut off the power supply to the relevant circuits to ensure there's no electricity running through the wiring.
2. Trim the cord leaving enough for electrical connections. From the end of the cord, strip the insulation 4" and then strip the end of the wires. Be sure not to nick the inner wires.
3. In accordance with local electrical codes, connect the fixture ground wire (bare copper or silver wire) to suitable ground. This may be a green ground screw on the mounting plate, which the ground wire should be tightly wrapped around or a house wire (green or bare copper wire without insulation).
4. Twist the bare ends of the following pairs of wires together using a wire nut to secure a connection:
  - a) Hot fixture wire (black) and hot power line wire from the junction box (hot to hot)
  - b) Neutral fixture wire (white) and neutral power line wire from the junction box (neutral to neutral)
5. Carefully tuck all the wires behind the mounting plate into the junction box.

### **III. Installing the Fixture**

1. Place and align the canopy over the mounting plate and secure it in place with the cap nuts.
2. Screw the lamp into the socket, referring to the label on the socket for Max Wattage information.